

Vetteworks C3 Fire Extinguisher Bracket Installation



Adjust seat all the way back position. Locate the front two seat bolts by lifting up carpet flaps covering the bolts. Using an 1/2" socket remove the front 2 seat bolts and carefully slide the C3 bracket over the two floor pan holes. Instruction is identical for driver side.

Replace the 2 original bolts with the new longer grade 8 bolts supplied. Tighten to 30 lbs



Place the Amerex bracket over the Vetteworks bracket and install the 3 button Allen bolt with a 5/32" Allen wrench.

Install the Amerex fire extinguisher.

Note: Vetteworks recommends customers to be familiar with the operation of your Amerex fire extinguisher. Please read Amerex instruction sheet.



Copyright 2002, 2003 Vetteworks LLC