

F-Body Extinguisher Bracket Instructions

Installing the F-Body bracket on the passenger side seat bolts.



1. Remove the 2 plastic nut covers. Use a 13mm wrench or socket to remove the front 2 locking nuts. Install the F-Body extinguisher bracket onto the 2 floor studs, replace the 2 locking nut and tighten. Replace the plastic nut covers. Install the Amerex extinguisher bracket onto the F-Body bracket with the 3 supplied 1/4" button Allen head bolts as shown and tighten with a 5/32 Allen wrench. Place the Amerex fire extinguisher in place.

Note:

Be familiar with the operation of your Amerex fire extinguisher and read the manufacture Instructions.

Tech Question call 253-223-6849

Copyright 2003, Vetteworks LLC